

## ASUS AX6100 Ai Mesh

### Shipment Content:

- 2 x Protective Case
- 2 x Router with 4 embedded Antennas
- 2 x 9V Power Adapter



### Quick Setup:

1. **Your Asus AX6100 Mesh WiFi** router system comes pre configured. They are also labeled for easy set-up, lets begin with the router labeled MAIN.
2. **Plug in the power adapter & a DHCP hard line** from the venue onto the MAIN router's WAN port. Press the power button on the side to turn on the router. *Allow 3-5 minutes for the router to light up "white" when ready.*




- 5G2, 5G1, 2.4G display the router is broadcasting WiFi.
- WAN (Internet), hardline connection established..
- Power LED, device is ready.

3. **Lift all 4 antennas** and position them upwards.
4. **Plug in the power adapter** into the router labeled MESH & power it on. It will connect automatically to the MAIN router. *Allow 1-3 minutes for the router to light up "white" when ready (WAN light will be off).*
5. **Lift the antennas** and position them upwards. *If you have more than one MESH unit in your order please repeat steps 4-5 for each one.*

6. **Connect your devices.**

**Connect your WIRED (e.g. Ethernet enabled Printer)** Connect the ethernet cable to one of the LAN (1-4) ports in the back of the router. Plug the other end of the cable into the printer. *The LAN LED on the router lights up when connected.*




**Connect your WIRELESS Devices (e.g. Tablet / PC)** Open the camera app on your device and scan the QR-Code on the bottom of the router. Alternatively use the default SSID (Wireless Network Name) on the bottom of the router along with the password in your *Important Documents Folder* to connect wirelessly.

**Via WPS (e.g. WPS enabled Printer)** Press and Hold the WPS button on the side of the router until the Power light starts blinking fast. Then proceed to set the printer on WPS mode as per its setup document. *Allow 1-2 minutes to establish connection.*

**Please DO NOT press the Reset button on the back of the router this will cause the Mesh system to un-sync**

### Setup Video Guide:

Scan this QR code with your phone camera for video.



### Contact our Support Team:

www.choose2rent.com/help  
 +1 (800) 622-6484 Ext. 3 (USA)  
 +49 40 226 360 - 590 (Europe)

# RENTAL EQUIPMENT SETUP GUIDE


## **Troubleshooting:**

*What if...*

... the router does not power up?	Please check if the power plugs are plugged in tightly. Switch On and Off again. <i>Wait 3 mins.</i>
... the WAN lights up Red? (MAIN)	The device is not getting an Internet connection, make sure the hardline is on the WAN port. Ask if the hardline from the venue has a splash screen or requires a MAC address.
... the LAN light is off?	No physical connection to printer or PC. Make sure the line is properly plugged and the other unit is powered up.
... the 2.4G light is off?	Your unit is pre-set to work only on the 5.0GHz wireless connection.
...the 5G1 & 5G2 lights are off?	Your unit is not broadcasting any wireless connectivity. Please check that your MAIN router has completely booted before powering on the MESH units.
...the MESH unit has no internet connection?	Switch On and Off. If a problem persists your units might be too far apart or there might be too much interference between them.

### **Setup Video Guide:**

Scan this QR code with your phone camera for video.



### **Contact our Support Team:**

[www.choose2rent.com/help](http://www.choose2rent.com/help)  
+1 (800) 622-6484 Ext. 3 (USA)  
+49 40 226 360 - 590 (Europe)