



Choose 2 Rent

Phone 1 (800) 622-6484


Fax 1 (866) 937-8254

info@choose2rent.com

www.choose2rent.com

How to set up your Premium Floor Stand

1. Insert the screw into the bottom of the base plate and with a screw driver, tighten it into the thread of the pole.



2. With the Allen Wrench provided, loosen the bolts on the clamp as needed and slide the clamp over the top of the floor stand pole.
3. Be sure to not tighten the clamp or block the opening in the pole for your charger cable.



Please call our support team if you need assistance
setting up your rental devices
1(800) 622-6484